

YOUR FIRST STEPS WITH THE DEVICE

1

Plug into socket. Device should automatically turn itself on.



2

Use the remote control to turn the device on/off and to change settings.

3

Insert USB or connect to WiFi to upload and play content.



BASIC SETTINGS



Set your language

Menu > OnScreen Display > Language > English



Check your time and date

Menu > System > Time > Clock Set > Date or Time > Enter the Date or Time



Change your keyboard language

Menu > System > Input Device Manager > Keyboard Language > English



Change picture mode

Menu > Picture > Picture Mode



Change PIN

Menu > System > Change PIN > Enter 0000 > Enter new PIN



Lock your content

Menu > System > Security > Enter PIN (default 0000) > Button Lock > On > Safety Lock On



Lock your device

Menu > System > Security > Enter PIN (default 0000) > Power On Button > On > Safety Lock On